

## TDXE6438 Wireless Timing Transmitter

### Features:

- Bidirectional communication by power line in high speed with the feedback function; can be compatible with popular product like X10.
- Wireless signal transmission in high speed; inquire about the working status of light or electrical appliance.
- Movable signal orientation design, easy to installation, is propitious to transmit the signal and stabilize the system.
- Incorporate central control and indirect On-off control.
- Inquire about the on or off status of the controlled appliance, feedback and display
- Show the time
- Timing control the on or off of the electrical appliance.
- Use noise suppression circuit inside to insure the signal not be jammed.

### Details:


Model: TDXE6438 Wireless Timing Transmitter	
Series	Control
Specification	220V 50Hz;
Received transmitting Frequency	433MHz
Static Power	<IW
Dimension	155X113X35mm
Receiving transmitting distance	30meter to 50 meter indoor

Notice: Please read this illustration before using.

- In study status, the system will exit the address setup if no order more than 30 seconds.

### Installation, Setup and Operation:

- Combined with TDXE6648 48 Key LCD Multi-Function Remote control, TDXE6438 Wireless Timing Transmitter can be installed in the place with receiving and transmitting the perfect signal.
- Can be installed in two ways: hanging and desk.


Communication confirmation and encrypt between the remote control and Wireless Timing Transmitter: press the Password key  5 seconds, the indicator light is bright.

I : Stop pressing this key, enter the study status of remote control password, then transmit an on or off signal from the studied control, the indicator light will shine three times. And the password of remote control transmits into the transmitter.

This transmitter can study four remote control passwords. As finished the study four times, it will auto-exit the study status as stopped pressing.







II : Press the password key ten seconds, all the studied passwords are deleted and the indicator light will shine seven times.


TDXE6438 wireless timing transmitter Keyboard:




**This transmitter has the functions of showing time, central control and timing control etc.**





Show the time:


Set the time: Press the key  ; enter the time setup status, at this time the second in the screen disappears. Press the key  or  to adjust the hour, press the key  or  to adjust the minute. And press the key  to finish the





setup. Or press the key  to cancel this setup. It will auto-exit the setup if no order more than 30 seconds.

#### Timing Control:


Set Timing: can set timing on or off for 16 sets of the electrical appliance. Press the key  the left of the screen will show 'PRG 01', which means setting timing for the first circuit. The right of the screen will show the timing. If have never set before, the screen will show 88: 88.



Press the key  or  to adjust the hour, press the key  or 

to adjust the minute, then press the key  to confirm and enter the automatic setup for on or off the electrical appliance: at that time the right of the screen will show the room code, cell code, function etc. if have never set before, the screen will show 'A: 01 ON', then press the key






 or  to adjust the room code, press the key  or  to



adjust the cell code, and press the key  or  to set on or off the light or

electrical appliance at that time. Then press the key  to finish the setup and enter the next setup for on or off light or electrical appliance.

As entered the timing setup status, press the key  to inquire about setups for each circuit; press the key  to cancel the setup.

**Central Control:** At the time show status, press the number key 1—8 to enter the central control.

I , Setup room code: press the key  to set the room code, and press the key  or  to confirm the room code that you hope this number stand for. Press the key  to store and exit. Or press the key  to exit directly.

II , operate the light or electrical appliance, first press the number key 1—8 to choose the appliance, press the function key  or  according your demand It will

exit the central control and return to the time show status if no order more than 5 seconds.

#### Contact Information

**Manufacturer: Taiyito Technology Co., Ltd**

Add: 1505 Rm, No.18 Fenghuli Building ,Anshan West Road, Nankai District 300192 Tianjin  
China

Manufacture Add: Hongqiao Science and Technology Zone

Tel: 022-27415471 27611356 27421307

Fax: 022-27611356-804 Post Code: 300192

E-mail: info@taiyito.net

Net: WWW.TAIYITO.NET

No notify as any changes of the product design and specification.